



- Paint the model with Testors Gloss Coat or Wet Look spray paint and allow to dry
- Cut the decal out with scissors or a sharp hobby knife and soak it in water for 10 seconds
- Larger decals can be cut into pieces because they can sometimes be difficult to work with
- Lay the decal on a damp paper towel for 1 minute
- Apply Microscale Microset to the area on the model where the decal will be applied
- Pull the decal off the backing paper and onto the model with a soft paintbrush
- Correctly position the decal and let it dry thoroughly
- Apply another coat of Gloss Coat or Wet look
- Allow to dry and finish the model with Dull Coat